General Information

General Specifications

ELIEL IN	JECTION			
Туре	Lombardini Unit Injectors			
Idle RPM (engine warm)	800-900			
Throttle Cable Free-Play (at lever)				
, , ,	RICAL			
	-			
Glow Plug Type	Lombardini			
Alternator	Denso 12V/40 Amp			
	SSIS			
Brake Type	Hydraulic w/Brake Lever Lock and Auxiliary Brake			
Tire Size	Front - 25 x 8-12 Rear - 25 x 10-12			
Tire Inflation Pressure	0.35 kg/cm² (5 psi)			
MISCELLANY				
Fuel Tank Capacity	20.81 L (5.5 U.S. gal.)			
Coolant Capacity	5.6 L (5.9 U.S. qt)			
Front Differential Capacity	275 ml (9.3 fl oz)*			
Rear Drive Capacity	250 ml (8.5 fl oz)*			
Engine Oil Capacity (with filter)	2.0 L (2.1 U.S. qt)			
Engine Oil Capacity (without filter)	1.9 L (2.0 U.S. qt)			
Transmission Capacity	600 ml (20.3 fl oz)			
Fuel (recommended)	Biodiesel Blend up to 20% (B20)/ 42-50 Cetane Diesel - #1 or #2/JP 5 or JP 8 Turbine			
Engine Oil (recommended)	SAE 10W-40			
Differential/Rear Drive Lubricant	SAE Approved 80W-90 Hypoid			
Transmission Lubricant	SAE Approved 80W-90 Hypoid			
Drive Belt Width (minimum)	31.25 mm (1.23 in.)			
Brake Fluid	DOT 4			
Taillight/Brakelight	12V/8W/27W			
Headlight	12V/27W (2)			

Specifications subject to change without notice.

* One inch below plug threads.

Torque Specifications

STEERING COMPONENTS					
Part	Part Bolted To		que N-m		
Handlebar Cap	Steering Post	20	27		
Steering Post Bearing Housing	Frame	20	27		
Steering Post Bearing Flange	Frame	20	27		
Tie Rod End	Knuckle/Steering Post	30	41		
EXHAUST COMPONENTS					
Exhaust Pipe	Exhaust Manifold	14	19		
Spark Arrester	Muffler	48 inlb	5		
ELECTRICAL COMPONENTS					
Ground Wire	Transmission	8	11		
CHASSIS COMPONENTS					
Shift Lever***	Shift Axle	8	11		

DRIVE TRAIN COMPONENTS

PartPart Bolted To ft-lbN- mFront Mounting BracketEngine2027Engine Mount (Upper)**Frame3548Engine Mount (Front/Rear)Frame2027Front Differential***Frame/Differential Bracket3852Rear Drive Gear CaseFrame3852Input HousingGear Case Housing2331Output Drive Yoke Nut*Output Shaft7298Differential Housing Cover**Differential Housing2331Drive Bevel Gear RetainingSecondary Output Shaft87118Nut**Secondary Output Shaft87118Secondary Drive/Bevel GearTransmission Case80108ShaftGear Case2331Pinion HousingGear Case2331Gear Case CoverGear Case2331Lock CollarDifferential Housing125170Hub NutShaft/Axle (min)200272Drain PlugFront Differential/Rear Drive425Fill PlugFront Differential/Rear Drive425Oil Drain PlugEngine1824WheelHub1519Brake HoseCaliper2027Brake HoseAuxiliary Brake Cylinder2027Brake HoseAuxiliary Brake Cylinder2027Brake HoseAuxiliary Brake Cylinder2027Brake HoseAuxiliary Brake Cylinder <td< th=""><th></th><th></th><th colspan="2">Torque</th></td<>			Torque	
Engine Mount (Upper)** Frame 35 48 Engine Mount (Front/Rear) Frame 20 27 Front Differential*** Frame/Differential Bracket 38 52 Rear Drive Gear Case Frame 38 52 Input Housing Gear Case Housing 23 31 Output Drive Yoke Nut* Output Shaft 72 98 Differential Housing Cover** Differential Housing 23 31 Drive Bevel Gear Retaining Nut** Secondary Output Shaft 87 118 Secondary Drive/Bevel Gear Shaft Transmission Case 80 108 Pinion Housing Gear Case 8 11 Gear Case Cover Gear Case 8 11 Gear Case Cover Gear Case 8 11 Indear Case Cover Gear Case 8 11 Gear Case 8 11 15 170 Hub Nut Shaft/Axle (min) 200 272 Drain Plug Front Differential/Rear Drive 16 22	Part	Part Bolted To	ft-lb	
Engine Mount (Front/Rear)Frame2027Front Differential***Frame/Differential Bracket3852Rear Drive Gear CaseFrame3852Input HousingGear Case Housing2331Output Drive Yoke Nut*Output Shaft7298Differential Housing Cover**Differential Housing2331Drive Bevel Gear Retaining Nut**Secondary Output Shaft87118Secondary Drive/Bevel Gear ShaftTransmission Case80108Pinion HousingGear Case2331Gear Case CoverGear Case811Gear Case CoverGear Case811Indear Case CoverGear Case811Gear Case CoverGear Case811Indear Case CoverGear Case2331Lock CollarDifferential Housing125170Hub NutShaft/Axle (min)200272Drian PlugFront Differential/Rear Drive1622Oil Drain PlugEngine1824WheelHub4561BRAKE COMPONENTSBrake HoseCaliper2027Brake HoseCaliper2027Brake HoseAuxiliary Brake Cylinder2027Brake HoseAuxiliary Brake Cylinder2027Brake HoseAuxiliary Brake Cylinder2027Brake HoseAuxiliary Brake Cylinder2027 <t< td=""><td>Front Mounting Bracket</td><td>Engine</td><td>20</td><td>27</td></t<>	Front Mounting Bracket	Engine	20	27
Front Differential***Frame/Differential Bracket3852Rear Drive Gear CaseFrame3852Input HousingGear Case Housing2331Output Drive Yoke Nut*Output Shaft7298Differential Housing Cover**Differential Housing2331Drive Bevel Gear Retaining Nut**Secondary Output Shaft87118Secondary Drive/Bevel Gear ShaftTransmission Case80108Pinion HousingGear Case2331Gear Case CoverGear Case2331Lock CollarDifferential Housing125170Hub NutShaft/Axle (min)200272Drain PlugFront Differential/Rear Drive425Fill PlugFront Differential/Rear Drive1622Oil Drain PlugEngine1824WheelHub4561BRAKE COMPONENTS2027Brake Disc***Hub1519Brake HoseAuxiliary Brake Cylinder2027Brake HoseAuxiliary Brake Cylinder2027Auxiliary Brake PedalLever Axle2027ArrmFrame5068Ball Joint Cap ScrewKnuckle3548Shock AbsorberUpper A-Arm5068Shock AbsorberUpper A-Arm5068Shock Absorber (Upper)Frame5068Shock Absorber (Lower)Lower A-Arm2027	Engine Mount (Upper)**	Frame	35	48
Rear Drive Gear CaseFrame3852Input HousingGear Case Housing2331Output Drive Yoke Nut*Output Shaft7298Differential Housing Cover**Differential Housing2331Drive Bevel Gear Retaining Nut**Secondary Output Shaft87118Secondary Drive/Bevel Gear ShaftTransmission Case80108Pinion HousingGear Case2534Ring Gear/Thrust Button*Gear Case2331Lock CollarDifferential Housing125170Hub NutShaft/Axle (min)200272Drain PlugFront Differential/Rear Drive42 inlb5Fill PlugFront Differential/Rear Drive42 inlb5Fill PlugEngine1824WheelHub4561BRAKE COMPONENTSBrake Disc***Hub1519Brake HoseCaliper2027Auxiliary Brake PedalLever Axle2534Caliper HolderKnuckle2027Auxiliary Brake PedalLever Axle2534Caliper HolderKnuckle3548Shock AbsorberUpper A-Arm5068Ball Joint Cap ScrewKnuckle3548Shock AbsorberUpper A-Arm5068Shock Absorber (Upper)Frame5068Shock Absorber (Lower)Lower A-Arm2027<	, ,	Frame	20	27
Input HousingGear Case Housing2331Output Drive Yoke Nut*Output Shaft7298Differential Housing Cover**Differential Housing2331Drive Bevel Gear Retaining Nut**Secondary Output Shaft87118Secondary Drive/Bevel Gear ShaftTransmission Case80108Pinion HousingGear Case2534Ring Gear/Thrust Button*Gear Case811Gear Case CoverGear Case2331Lock CollarDifferential Housing125170Hub NutShaft/Axle (min)200272Drain PlugFront Differential/Rear Drive1622Oil Drain PlugEngine1824WheelHub4561BRAKE COMPONENTS1919Brake HoseCaliper2027Brake HoseCaliper2027Brake HoseAuxiliary Brake Cylinder2027Auxiliary Brake PedalLever Axle2534Caliper HolderKnuckle2027Auxiliary/Hydraulic Caliper****Knuckle2027ArmFrame5068Shock AbsorberUpper A-Arm5068Shock AbsorberFrame5068Shock Absorber (Upper)Frame5068Shock Absorber (Lower)Lower A-Arm2027	Front Differential***	Frame/Differential Bracket	38	52
Output Drive Yoke Nut*Output Shaft7298Differential Housing Cover**Differential Housing2331Drive Bevel Gear Retaining Nut**Secondary Output Shaft87118Secondary Drive/Bevel Gear ShaftTransmission Case80108Pinion HousingGear Case2534Ring Gear/Thrust Button*Gear Case8111Gear Case CoverGear Case2331Lock CollarDifferential Housing125170Hub NutShaft/Axle (min)200272Drain PlugFront Differential/Rear Drive425Fill PlugFront Differential/Rear Drive1622Oil Drain PlugEngine1824WheelHub4561BRAKE COMPONENTS2027Brake Disc***Hub1519Brake HoseCaliper2027Auxiliary Brake PedalLever Axle2027Auxiliary Brake PedalLever Axle2027AuxiliaryHydraulic Caliper****Knuckle2027ArmFrame5068Ball Joint Cap ScrewKnuckle3548Shock AbsorberUpper A-Arm5068Shock AbsorberUpper A-Arm5068Shock AbsorberKnuckle3548Shock Absorber (Upper)Frame5068Shock Absorber (Lower)Lower A-Arm2027	Rear Drive Gear Case	Frame	38	52
Differential Housing Cover**Differential Housing2331Drive Bevel Gear Retaining Nut**Secondary Output Shaft87118Secondary Drive/Bevel Gear ShaftTransmission Case80108Pinion HousingGear Case2534Ring Gear/Thrust Button*Gear Case811Gear Case CoverGear Case2331Lock CollarDifferential Housing125170Hub NutShaft/Axle (min)200272Drain PlugFront Differential/Rear Drive425Fill PlugFront Differential/Rear Drive1622Oil Drain PlugEngine1824WheelHub4561BRAKE COMPONENTS1919Brake HoseCaliper2027Brake HoseMaster Cylinder2027Brake HoseAuxiliary Brake Cylinder2027Auxiliary Brake PedalLever Axle2534Caliper HolderKnuckle2027Auxiliary/Hydraulic Caliper****Knuckle2027Auxiliary/Hydraulic Caliper****Knuckle3548Shock AbsorberFrame5068Shock AbsorberUpper A-Arm5068Shock Absorber (Upper)Frame5068Shock Absorber (Upper)Frame5068Shock Absorber (Lower)Lower A-Arm2027		Gear Case Housing	23	31
Drive Bevel Gear Retaining Nut**Secondary Output Shaft87118Secondary Drive/Bevel Gear ShaftTransmission Case80108Pinion HousingGear Case2534Ring Gear/Thrust Button*Gear Case811Gear Case CoverGear Case2331Lock CollarDifferential Housing125170Hub NutShaft/Axle (min)200272Drain PlugFront Differential/Rear Drive425Fill PlugFront Differential/Rear Drive1622Oil Drain PlugEngine1824WheelHub4561BRAKE COMPONENTS1519Brake Disc***Hub1519Brake HoseCaliper2027Brake HoseAuxiliary Brake Cylinder2027Auxiliary Brake PedalLever Axle2534Caliper HolderKnuckle2027Auxiliary Brake PedalLever Axle2534Caliper HolderKnuckle3548Shock AbsorberFrame5068Ball Joint Cap ScrewKnuckle3548Shock Absorber (Upper)Frame5068Shock Absorber (Upper)Frame5068Shock Absorber (Upper)Frame5068Shock Absorber (Lower)Lower A-Arm2027	Output Drive Yoke Nut*	Output Shaft	72	98
Nut**Image: Secondary Drive/Bevel Gear ShaftTransmission Case80108Pinion HousingGear Case2534Ring Gear/Thrust Button*Gear Case811Gear Case CoverGear Case2331Lock CollarDifferential Housing125170Hub NutShaft/Axle (min)200272Drain PlugFront Differential/Rear Drive425Fill PlugFront Differential/Rear Drive1622Oil Drain PlugEngine1824WheelHub4561BRAKE COMPONENTS1519Brake Disc***Hub1519Brake HoseCaliper2027Brake HoseMaster Cylinder2027Brake HoseAuxiliary Brake Cylinder2027Auxiliary Brake PedalLever Axle2534Caliper HolderKnuckle2027Auxiliary/Hydraulic Caliper****Knuckle2027A-ArmFrame5068Ball Joint Cap ScrewKnuckle3548Shock AbsorberUpper A-Arm5068Shock Absorber (Upper)Frame5068Shock Absorber (Lower)Lower A-Arm2027	Differential Housing Cover**	Differential Housing	23	31
ShaftInterferenceInterferencePinion HousingGear Case2534Ring Gear/Thrust Button*Gear Case811Gear Case CoverGear Case2331Lock CollarDifferential Housing125170Hub NutShaft/Axle (min)200272Drain PlugFront Differential/Rear Drive1622Oil Drain PlugEngine1824WheelHub4561BRAKE COMPONENTSBrake Disc***Hub1519Brake HoseCaliper2027Brake HoseMaster Cylinder2027Auxiliary Brake PedalLever Axle2027Auxiliary/Hydraulic Caliper****Knuckle2027Auxiliary/Hydraulic Caliper****Knuckle3548Shock AbsorberUpper A-Arm5068Shock AbsorberUpper A-Arm5068Shock Absorber (Upper)Frame5068Shock Absorber (Lower)Lower A-Arm2027	Drive Bevel Gear Retaining Nut**	Secondary Output Shaft	87	118
Ring Gear/Thrust Button*Gear Case811Gear Case CoverGear Case2331Lock CollarDifferential Housing125170Hub NutShaft/Axle (min)200272Drain PlugFront Differential/Rear Drive42 inlb5Fill PlugFront Differential/Rear Drive1622Oil Drain PlugEngine1824WheelHub4561BRAKE COMPONENTSBrake Disc***Hub1519Brake HoseCaliper2027Brake HoseMaster Cylinder2027Brake HoseAuxiliary Brake Cylinder2027Auxiliary Brake PedalLever Axle2534Caliper HolderKnuckle2027Auxiliary/Hydraulic Caliper****Knuckle3548Shock AbsorberFrame5068Ball Joint Cap ScrewKnuckle3548Shock AbsorberUpper A-Arm5068Shock Absorber (Upper)Frame5068Shock Absorber (Upper)Frame5068Shock Absorber (Lower)Lower A-Arm2027		Transmission Case	80	108
Gear Case CoverGear Case2331Lock CollarDifferential Housing125170Hub NutShaft/Axle (min)200272Drain PlugFront Differential/Rear Drive42 inlb5Fill PlugFront Differential/Rear Drive1622Oil Drain PlugEngine1824WheelHub4561BRAKE COMPONENTSBrake Disc***Hub1519Brake HoseCaliper2027Brake HoseMaster Cylinder2027Brake HoseAuxiliary Brake Cylinder2027Auxiliary Brake PedalLever Axle2534Caliper HolderKnuckle2027Auxiliary/Hydraulic Caliper****Knuckle2027A-ArmFrame5068Ball Joint Cap ScrewKnuckle3548Shock AbsorberUpper A-Arm5068SuspensionCOMPONENTS (Rear)Jo68Shock Absorber (Upper)Frame5068Shock Absorber (Lower)Lower A-Arm2027	Pinion Housing	Gear Case	25	34
Lock CollarDifferential Housing125170Hub NutShaft/Axle (min)200272Drain PlugFront Differential/Rear Drive425Fill PlugFront Differential/Rear Drive1622Oil Drain PlugEngine1824WheelHub4561BRAKE COMPONENTSBrake Disc***Hub1519Brake HoseCaliper2027Brake HoseMaster Cylinder2027Brake HoseAuxiliary Brake Cylinder2027Auxiliary Brake PedalLever Axle2027Auxiliary Brake PedalLever Axle2027Auxiliary/Hydraulic Caliper****Knuckle2027Auxiliary/Hydraulic Caliper****Knuckle3548Shock AbsorberFrame5068Ball Joint Cap ScrewKnuckle3548Shock AbsorberFrame5068Shock Absorber (Upper)Frame5068Shock Absorber (Lower)Lower A-Arm2027	Ring Gear/Thrust Button*	Gear Case	8	11
Hub NutShaft/Axle (min)200272Drain PlugFront Differential/Rear Drive42 inlb5 inlbFill PlugFront Differential/Rear Drive1622Oil Drain PlugEngine1824WheelHub4561BRAKE COMPONENTSBrake Disc***Hub1519Brake HoseCaliper2027Brake HoseMaster Cylinder2027Brake HoseAuxiliary Brake Cylinder2027Auxiliary Brake PedalLever Axle2027Auxiliary HolderKnuckle2027Auxiliary/Hydraulic Caliper****Knuckle2027Auxiliary/Hydraulic CaliperFrame5068Ball Joint Cap ScrewKnuckle3548Shock AbsorberFrame5068SuspensionCOMPONENTS (Rear)V68A-ArmFrame5068Shock Absorber (Upper)Frame5068Shock Absorber (Lower)Lower A-Arm2027	Gear Case Cover	Gear Case	23	31
Drain PlugFront Differential/Rear Drive inlb42 inlb5Fill PlugFront Differential/Rear Drive1622Oil Drain PlugEngine1824WheelHub4561BRAKE COMPONENTSBrake Disc***Hub1519Brake HoseCaliper2027Brake HoseMaster Cylinder2027Brake HoseAuxiliary Brake Cylinder2027Brake HoseAuxiliary Brake Cylinder2027Auxiliary Brake PedalLever Axle2534Caliper HolderKnuckle2027Auxiliary/Hydraulic Caliper****Knuckle2027A-ArmFrame5068Ball Joint Cap ScrewKnuckle3548Shock AbsorberUpper A-Arm5068Suspension Components (Rear)5068Shock AbsorberFrame5068Shock Absorber (Upper)Frame5068Shock Absorber (Lower)Lower A-Arm2027	Lock Collar	Differential Housing	125	170
Inn. HugInn. HugInn. HugFill PlugFront Differential/Rear Drive1622Oil Drain PlugEngine1824WheelHub4561BRAKE COMPONENTSBrake Disc***Hub1519Brake HoseCaliper2027Brake HoseMaster Cylinder2027Brake HoseAuxiliary Brake Cylinder2027Brake HoseAuxiliary Brake Cylinder2027Auxiliary Brake PedalLever Axle2534Caliper HolderKnuckle2027Auxiliary/Hydraulic Caliper****Knuckle2027A-ArmFrame5068Ball Joint Cap ScrewKnuckle3548Shock AbsorberUpper A-Arm5068Suspension Components (Rear)5068Shock AbsorberFrame5068Shock Absorber (Upper)Frame5068Shock Absorber (Lower)Lower A-Arm2027	Hub Nut	Shaft/Axle (min)	200	272
Oil Drain Plug Engine 18 24 Wheel Hub 45 61 BRAKE COMPONENTS Brake Disc*** Hub 15 19 Brake Hose Caliper 20 27 Brake Hose Master Cylinder 20 27 Brake Hose Master Cylinder 20 27 Brake Hose Auxiliary Brake Cylinder 20 27 Auxiliary Brake Pedal Lever Axle 20 27 Auxiliary/Hydraulic Caliper**** Knuckle 20 27 Auxiliary/Hydraulic Caliper**** Knuckle 20 27 ALXIBERSION COMPONENTS (Front) Image: Colored State Sta	Drain Plug	Front Differential/Rear Drive		5
Wheel Hub 45 61 BRAKE COMPONENTS Image: Second Sec	Fill Plug	Front Differential/Rear Drive	16	22
BRAKE COMPONENTSBrake Disc***Hub1519Brake HoseCaliper2027Brake HoseMaster Cylinder2027Brake HoseAuxiliary Brake Cylinder2027Brake HoseAuxiliary Brake Cylinder2027Auxiliary Brake PedalLever Axle2534Caliper HolderKnuckle2027Auxiliary/Hydraulic Caliper****Knuckle2027SUSPENSION COMPONENTS (Front)June 1005068Ball Joint Cap ScrewKnuckle3548Shock AbsorberUpper A-Arm5068Shock AbsorberFrame5068Shock AbsorberFrame5068Shock Absorber (Upper)Frame5068Shock Absorber (Lower)Lower A-Arm2027	Oil Drain Plug	Engine	18	24
Brake Disc***Hub1519Brake HoseCaliper2027Brake HoseMaster Cylinder2027Brake HoseAuxiliary Brake Cylinder2027Auxiliary Brake PedalLever Axle2534Caliper HolderKnuckle2027Auxiliary/Hydraulic Caliper****Knuckle2027SUSPENSION COMPONENTS (Front)SUSPENSION COMPONENTS (Front)48A-ArmFrame5068Ball Joint Cap ScrewKnuckle3548Shock AbsorberFrame5068Shock AbsorberUpper A-Arm5068Shock AbsorberFrame5068Shock Absorber (Upper)Frame5068Shock Absorber (Upper)Frame5068Shock Absorber (Lower)Lower A-Arm2027			45	61
Brake HoseCaliper2027Brake HoseMaster Cylinder2027Brake HoseAuxiliary Brake Cylinder2027Auxiliary Brake PedalLever Axle2534Caliper HolderKnuckle2027Auxiliary/Hydraulic Caliper****Knuckle2027Auxiliary/Hydraulic Caliper****Knuckle2027SUSPENSION COMPONENTS (Front)June5068Ball Joint Cap ScrewKnuckle3548Shock AbsorberFrame5068Shock AbsorberUpper A-Arm5068Shock AbsorberFrame5068Shock Absorber (Upper)Frame5068Shock Absorber (Upper)Frame5068Shock Absorber (Upper)Frame5068Shock Absorber (Lower)Lower A-Arm2027	BRAKE	COMPONENTS		
Brake HoseMaster Cylinder2027Brake HoseAuxiliary Brake Cylinder2027Auxiliary Brake PedalLever Axle2534Caliper HolderKnuckle2027Auxiliary/Hydraulic Caliper****Knuckle2027SUSPENSION COMPONENTS (Front)A-ArmFrame5068Ball Joint Cap ScrewKnuckle3548Shock AbsorberFrame5068Shock AbsorberUpper A-Arm5068Shock AbsorberFrame5068Shock Absorber (Upper)Frame5068Shock Absorber (Upper)Frame5068Shock Absorber (Upper)Frame5068Shock Absorber (Upper)Frame5068Shock Absorber (Lower)Lower A-Arm2027	Brake Disc***	Hub	15	19
Brake HoseAuxiliary Brake Cylinder2027Auxiliary Brake PedalLever Axle2534Caliper HolderKnuckle2027Auxiliary/Hydraulic Caliper****Knuckle2027SUSPENSION COMPONENTS (Front)A-ArmFrame5068Ball Joint Cap ScrewKnuckle3548Shock AbsorberFrame5068Suspension Components (Rear)5068Shock AbsorberFrame5068Shock AbsorberFrame5068Shock Absorber (Upper)Frame5068Shock Absorber (Upper)Frame5068Shock Absorber (Lower)Lower A-Arm2027	Brake Hose	Caliper	20	27
Auxiliary Brake PedalLever Axle2534Caliper HolderKnuckle2027Auxiliary/Hydraulic Caliper****Knuckle2027SUSPENSION COMPONENTS (Front)A-ArmFrame5068Ball Joint Cap ScrewKnuckle3548Shock AbsorberFrame5068Suspension Components (Rear)5068Suspension Components (Rear)5068Shock AbsorberFrame5068Shock Absorber (Upper)Frame5068Shock Absorber (Upper)Frame5068Shock Absorber (Lower)Lower A-Arm2027	Brake Hose	Master Cylinder	20	27
Caliper HolderKnuckle2027Auxiliary/Hydraulic Caliper****Knuckle2027SUSPENSION COMPONENTS (Front)A-ArmFrame5068Ball Joint Cap ScrewKnuckle3548Shock AbsorberFrame5068Suspension Components (Rear)5068Suspension Components (Rear)5068Shock AbsorberFrame5068Shock Absorber (Upper)Frame5068Shock Absorber (Upper)Frame5068Shock Absorber (Lower)Lower A-Arm2027	Brake Hose	Auxiliary Brake Cylinder	20	27
Auxiliary/Hydraulic Caliper****Knuckle2027SUSPENSION COMPONENTS (Front)A-ArmFrame5068Ball Joint Cap ScrewKnuckle3548Shock AbsorberFrame5068Shock AbsorberUpper A-Arm5068SUSPENSION COMPONENTS (Rear)A-ArmFrame5068Shock Absorber (Upper)Frame5068Shock Absorber (Upper)Frame5068Shock Absorber (Lower)Lower A-Arm2027	Auxiliary Brake Pedal	Lever Axle	25	34
SUSPENSION COMPONENTS (Front)A-ArmFrame5068Ball Joint Cap ScrewKnuckle3548Shock AbsorberFrame5068Shock AbsorberUpper A-Arm5068SUSPENSION COMPONENTS (Rear)A-ArmFrame5068Shock Absorber (Upper)Frame5068Shock Absorber (Upper)Lower A-Arm2027	-		20	27
A-ArmFrame5068Ball Joint Cap ScrewKnuckle3548Shock AbsorberFrame5068SUSPENSION COMPONENTS (Rear)A-ArmFrame5068Shock Absorber (Upper)Frame5068Shock Absorber (Upper)Frame5068Shock Absorber (Lower)Lower A-Arm2027			20	27
Ball Joint Cap ScrewKnuckle3548Shock AbsorberFrame5068Shock AbsorberUpper A-Arm5068SUSPENSION COMPONENTS (Rear)A-ArmFrame5068Shock Absorber (Upper)Frame5068Shock Absorber (Upper)Lower A-Arm2027			50	68
Shock AbsorberFrame5068Shock AbsorberUpper A-Arm5068SUSPENSION COMPONENTS (Rear)A-ArmFrame5068Shock Absorber (Upper)Frame5068Shock Absorber (Lower)Lower A-Arm2027				
Shock AbsorberUpper A-Arm5068SUSPENSION COMPONENTS (Rear)A-ArmFrame5068Shock Absorber (Upper)Frame5068Shock Absorber (Lower)Lower A-Arm2027				68
SUSPENSION COMPONENTS (Rear)A-ArmFrame5068Shock Absorber (Upper)Frame5068Shock Absorber (Lower)Lower A-Arm2027				68
A-ArmFrame5068Shock Absorber (Upper)Frame5068Shock Absorber (Lower)Lower A-Arm2027				
Shock Absorber (Upper)Frame5068Shock Absorber (Lower)Lower A-Arm2027			50	68
Shock Absorber (Lower) Lower A-Arm 20 27				
	. ,			

* w/Red Loctite #271

** w/Green Loctite #609

*** w/Blue Loctite #243

**** "Patch-Lock"

Download this Manual